

Get to know your control panel

Everything is operated with **2 buttons**. Look at the photo and find each part before you start.



- 1 Display.** Shows the power level, the schedule or error warnings.
- 2 Left button**  / . Changes the power and turns sunrise/sunset on.
- 3 Right button** . Used to set the on/off schedule (timer).
- 4 TIMER light** . On = the timer is active.
- 5 SR/SS light** . On = sunrise/sunset is active.

Two ways to press

SHORT PRESS

Press and release straight away, like a click. Each click moves to the next option.

LONG PRESS (3 s)

Hold the button down and slowly count "**one, two, three**". Then let go.

There is no "save" or "OK" button. For every setting, just stop pressing: the panel automatically saves whatever is on the display.

1 Changing the power

- 1** Give the left button  a **short press**.
- 2** Each click changes the power in this order:

630

→

473

→

315

→

158

→

OFF

→

630

...
- 3** When you see the power you want, **stop pressing**. It is now saved.

The numbers are watts (W): 630 = maximum power, 158 = minimum, **OFF** = light off.



Running at 630 W



Off (OFF)

Important: error warnings



E-01

The mains voltage is **too high**.



E-02

The mains voltage is **too low**.

If you see either of these warnings, **unplug the panel from the mains as soon as possible** to avoid damaging it.

2 Setting the schedule (timer)

The timer switches the light on and off by itself, every day. The display shows 4 digits: **the first 2** are the hours the light stays on and **the last 2** are the hours it stays off.

- 1 Give the right button a **short press**.
- 2 Keep clicking until you see the programme you want (see the table below).
- 3 **Stop pressing.** The display flashes **5 times**: this means it has been saved.
- 4 Check that the **TIMER** light is on. If it is, everything is correct.



On display	1212	1806	1905	2004	2103	...and so on
Light on	12 h	18 h	19 h	20 h	21 h	Always adds up to 24 h
Light off	12 h	6 h	5 h	4 h	3 h	

Want a custom schedule?

Keep pressing until you have gone through all the programmes. You can then set **the ON hours first** (01 to 23) and **then the OFF hours** (01 to 23). Stop pressing and wait for the 5 flashes.

Want to remove the timer?

Give the right button a **long press (3 s)**. The schedule is deleted and the **TIMER** light goes out.

3 Sunrise / Sunset

With this function the light does not switch on or off suddenly: it **gradually brightens when switching on** (sunrise) and **gradually dims when switching off** (sunset). Each transition lasts **20 minutes**.

- 1 Give the left button a **long press (3 s)** (it is the same button as the power one).
- 2 Look at the **SR/SS** light: **on** = function enabled; **off** = function disabled.
- 3 To change it again, repeat the long press.



4 Master Control (several panels at once)

If you have several panels connected to each other, you can control them all from just one: the **master** panel. The others copy what it does.

- 1 On **each panel**, hold down **both buttons at the same time for 3 s**. The display shows **FL**.
- 2 Once **all** of them show FL, adjust the master panel and the rest will follow.
- 3 To exit FL mode, do the same again: both buttons at once, 3 s.

A panel that is not in FL mode will not follow the master. If a unit does not have the Master Control function, you will need an external controller.

